

System beskrivelse

systemet består af 2 DMX linjer.

Lamperne hænger på 3 bjælker.

Front bjælke hænger over publikum ca. 5 meter fra scenen

Midter bjælke sidder over scene og kan flyttes mellem scenekant og bagerste bjælke.

Bagerste bjælke (bagtæppet) kan flyttes mellem midter bjælke og bagvæggen.

DMX 1 er front lamperne (1-8) placeret på front bjælken

Samt 2 (9-10) lamper på midter bjælken vendt mod publikum (blinder)

De øvrige kanaler på DMX 1 er uden betydning for jer.

DMX 2 er RGB lamper mover m.m.

Moving head 1-4 er små mover placeret på midter bjælken

RGB Midt er 2 RGB lamper i hver siden af midter bjælken. Pejrer normalt mod Center af scenen.

Hero Wash 300 FC 1 - 6 er placeret på bagerste bjælke. (bagtæppet er også monteret på denne bjælke)

Portable LED bar 1-2 er løse bar med 4 faste washer RGB på hver, stående på lav (0.5m) eller høj (2m) stativer.

De 6 sidelamper er hvide LED lamper placeret i hver siden af scenen forrest ved scenekanten i ca. 2.5 m højde.

Alle stik er 3 pol XLR.

Gæste tekniker sørger selv for evt. converter til medbragt udstyr.

*Alt efterlades som det er modtaget.

Afviklende lystekniker har det fulde ansvar for anlægget indtil det er afleveret til huset tekniker

Revideret d. 1-10-23

DMX 1

Kanal	Enhed	Formål
1	Par, front 1	Dimmer
2	Par, front 2	Dimmer
3	Par, front 3	Dimmer
4	Par, front 4	Dimmer
5	Par, front 5	Dimmer
6	Par, front 6	Dimmer
7	Par, front 7	Dimmer
8	Par, front 8	Dimmer
9	Par, midt venstre	Dimmer
10	Par, midt højre	Dimmer
11	Ekstra stik 11	Dimmer
12	Ekstra stik 12	Dimmer
13	Ekstra udgang 5	Dimmer
14	Ekstra udgang 6	Dimmer
15		
16		
17		
18		
19		
20		
21		
22		
23		
24		

DMX 2

Kanal	Enhed	Formål	Model	Note
1	Moving head 1	Pan	Showtec, Phantom 65 Spot	<u>13 kanaler</u>
2		Tilt		
3		Upan		
4		Utilt		
5		Pantilt_speed		
6		Dimmer		
7		Shutter		closed,0,0 open,12,12 strobe,16,131 pulse_open,132,167 pulse_close,168,203 pulse_strobe,204,239 random_strobe,240,250 open,255,255
8		Color		white,0,0 red,10,10 yellow,17,17 green,23,23 light_blue,31,31 orange,38,38 pink,45,45 light_green,52,52 uv,60,60 index,65,127 right_rotate,128,191 left_rotate,192,255
9		Gobo		1)
10		Gobo_rotate		no_function,0,0 right_rotate,8,119 left_rotate,120,231 bouncing,232,255
11		Prism		no_function,0,0 prism,255,255
12		control		no_function,0,0 blackout_moves,12,12 reset_pan,150,150 reset_tilt,160,160 reset_color,170,170 reset_gobo,180,180 reset_prism,190,199 reset,200,200
13		Effect_macro		2)
14	Moving head 2	Pan	Showtec, Phantom 65 Spot	<u>13 kanaler</u>
15		Tilt		
16		Upan		
17		Utilt		
18		Pantilt_speed		
19		Dimmer		
20		Shutter		closed,0,0 open,12,12 strobe,16,131 pulse_open,132,167 pulse_close,168,203 pulse_strobe,204,239 random_strobe,240,250 open,255,255
21		Color		white,0,0 red,10,10 yellow,17,17 green,23,23 light_blue,31,31 orange,38,38 pink,45,45 light_green,52,52 uv,60,60 index,65,127 right_rotate,128,191 left_rotate,192,255
22		Gobo		1)
23		Gobo_rotate		no_function,0,0 right_rotate,8,119 left_rotate,120,231 bouncing,232,255
24		Prism		no_function,0,0 prism,255,255
25		control		no_function,0,0 blackout_moves,12,12 reset_pan,150,150 reset_tilt,160,160 reset_color,170,170 reset_gobo,180,180 reset_prism,190,199 reset,200,200
26		Effect_macro		2)
27	Moving head 3	Pan	Showtec, Phantom 65 Spot	<u>13 kanaler</u>
28		Tilt		
29		Upan		
30		Utilt		
31		Pantilt_speed		
32		Dimmer		
33		Shutter		closed,0,0 open,12,12 strobe,16,131 pulse_open,132,167 pulse_close,168,203 pulse_strobe,204,239 random_strobe,240,250 open,255,255
34		Color		white,0,0 red,10,10 yellow,17,17 green,23,23 light_blue,31,31 orange,38,38 pink,45,45 light_green,52,52 uv,60,60 index,65,127 right_rotate,128,191 left_rotate,192,255
35		Gobo		1)
36		Gobo_rotate		no_function,0,0 right_rotate,8,119 left_rotate,120,231 bouncing,232,255
37		Prism		no_function,0,0 prism,255,255
38		control		no_function,0,0 blackout_moves,12,12 reset_pan,150,150 reset_tilt,160,160 reset_color,170,170 reset_gobo,180,180 reset_prism,190,199 reset,200,200
39		Effect_macro		2)
40	Moving head 4	Pan	Showtec, Phantom 65 Spot	<u>13 kanaler</u>
41		Tilt		
42		Upan		
43		Utilt		
44		Pantilt_speed		
45		Dimmer		
46		Shutter		closed,0,0 open,12,12 strobe,16,131 pulse_open,132,167 pulse_close,168,203 pulse_strobe,204,239 random_strobe,240,250 open,255,255
47		Color		white,0,0 red,10,10 yellow,17,17 green,23,23 light_blue,31,31 orange,38,38 pink,45,45 light_green,52,52 uv,60,60 index,65,127 right_rotate,128,191 left_rotate,192,255
48		Gobo		1)
49		Gobo_rotate		no_function,0,0 right_rotate,8,119 left_rotate,120,231 bouncing,232,255
50		Prism		no_function,0,0 prism,255,255
51		control		no_function,0,0 blackout_moves,12,12 reset_pan,150,150 reset_tilt,160,160 reset_color,170,170 reset_gobo,180,180 reset_prism,190,199 reset,200,200
52		Effect_macro		2)
53				
63	RBG Midt venstre	Red	Ukendt	<u>7 kanaler</u>

64	Green		
65	Blue		
66	Macro_mode		off,0,0 macro,255,255
67	Shutter		open,0,0 strobe,16,255
68	Mode		off,0,0 macro,255,255
69	dimmer		
70 RBG Midt højre	Red	Ukendt	<u>7 kanaler</u>
71	Green		
72	Blue		
73	Macro_mode		off,0,0 macro,255,255
74	Shutter		open,0,0 strobe,16,255
75	Mode		off,0,0 macro,255,255
76	dimmer		
125 Hazer	smoke	Ukendt	<u>2 kanaler</u>
126	Fan		
155 Venstre side øverst	Color Marco	ADJ Flat par TW12	<u>2 kanaler</u>
156	Dimmer		
157 Højre side øverst	Color Marco	ADJ Flat par TW12	<u>2 kanaler</u>
158	Dimmer		
159 Venstre side midt	Cool white	ADJ CWWW 9	<u>5 kanaler</u>
160	Warm white		
161	Color tone		
162	Strobing		
163	dimmer		
164 Højre side midt	Cool white	ADJ CWWW 9	<u>5 kanaler</u>
165	Warm white		
166	Color tone		
167	Strobing		
168	dimmer		
169 Venstre side nederst	Cool white	ADJ CWWW 9	<u>5 kanaler</u>
170	Warm white		
171	Color tone		
172	Strobing		
173	dimmer		
174 Højre side nederst	Cool white	ADJ CWWW 9	<u>5 kanaler</u>
175	Warm white		
176	Color tone		
177	Strobing		
178	dimmer		
179			
180 Hero Wash 300 FC #1	Pan	Varytec, Hero Wash 300 FC	<u>26 kanaler</u>
181	Upan		
182	Tilt		
183	Utilt		
184	pan-tilt speed		
185	zoom		
186	Dimmer		
187	Shutter		
188	Red		
189	Green		
190	Blue		
191	White		
192	Red		
193	Green		
194	Blue		

195	White		
196	Red		
197	Green		
198	Blue		
199	White		
200	Linear CTO -color temp		
201	Color Marco		
202	Segment pattern 1 to 18		
203	Transition		
204	Zoom automatic programme with decreasing speed, 1 (fast)...8 (slow)		
205	pan_tilt_macro		
206	Hero Wash 300 FC #2	Pan	Varytec, Hero Wash 300 FC <u>26 kanaler</u>
207	Upan		
208	Tilt		
209	Utilt		
210	pan-tilt speed		
211	zoom		
212	Dimmer		
213	Shutter		
214	Red		
215	Green		
216	Blue		
217	White		
218	Red		
219	Green		
220	Blue		
221	White		
222	Red		
223	Green		
224	Blue		
225	White		
226	Linear CTO -color temp		
227	Color Marco		
228	Segment pattern 1 to 18		
229	Transition		
230	Zoom automatic programme with decreasing speed, 1 (fast)...8 (slow)		
231	pan_tilt_macro		
232	Hero Wash 300 FC #3	Pan	Varytec, Hero Wash 300 FC <u>26 kanaler</u>
233	Upan		
234	Tilt		
235	Utilt		
236	pan-tilt speed		
237	zoom		
238	Dimmer		
239	Shutter		
240	Red		
241	Green		
242	Blue		
243	White		
244	Red		
245	Green		
246	Blue		
247	White		
248	Red		
249	Green		
250	Blue		
251	White		

252	Linear CTO -color temp		
253	Color Marco		
254	Segment pattern 1 to 18		
255	Transition		
256	Zoom automatic programme with decreasing speed, 1 (fast)...8 (slow)		
257	pan_tilt_macro		
258	Hero Wash 300 FC #4	Pan	Varytec, Hero Wash 300 FC 26 kanaler
259	Upan		
260	Tilt		
261	Utilt		
262	pan-tilt speed		
263	zoom		
264	Dimmer		
265	Shutter		
266	Red		
267	Green		
268	Blue		
269	White		
270	Red		
271	Green		
272	Blue		
273	White		
274	Red		
275	Green		
276	Blue		
277	White		
278	Linear CTO -color temp		
279	Color Marco		
280	Segment pattern 1 to 18		
281	Transition		
282	Zoom automatic programme with decreasing speed, 1 (fast)...8 (slow)		
283	pan_tilt_macro		
284	Hero Wash 300 FC #5	Pan	Varytec, Hero Wash 300 FC 26 kanaler
285	Upan		
286	Tilt		
287	Utilt		
288	pan-tilt speed		
289	zoom		
290	Dimmer		
291	Shutter		
292	Red		
293	Green		
294	Blue		
295	White		
296	Red		
297	Green		
298	Blue		
299	White		
300	Red		
301	Green		
302	Blue		
303	White		
304	Linear CTO -color temp		
305	Color Marco		
306	Segment pattern 1 to 18		
307	Transition		
308	Zoom automatic programme with decreasing speed, 1 (fast)...8 (slow)		

309	pan_tilt_macro		
310	Hero Wash 300 FC #6	Varytec, Hero Wash 300 FC	26 kanaler
311	Upan		
312	Tilt		
313	Utilt		
314	pan-tilt speed		
315	zoom		
316	Dimmer		
317	Shutter		
318	Red		
319	Green		
320	Blue		
321	White		
322	Red		
323	Green		
324	Blue		
325	White		
326	Red		
327	Green		
328	Blue		
329	White		
330	Linear CTO -color temp		
331	Color Marco		
332	Segment pattern 1 to 18		
333	Transition		
334	Zoom automatic programme with decreasing speed, 1 (fast)...8 (slow)		
335	pan_tilt_macro		

1) Miscellaneous/open,0,0 Miscellaneous/gobo1,12,12 Miscellaneous/gobo2,20,20 Miscellaneous/gobo3,28,28 Miscellaneous/gobo4,36,36 Miscellaneous/gobo5,44,44 Miscellaneous/gobo6,52,52
Miscellaneous/gobo7,60,60 Miscellaneous/shake_gobo7,64,71 Miscellaneous/shake_gobo6,72,79 Miscellaneous/shake_gobo5,80,87 Miscellaneous/shake_gobo4,88,95 Miscellaneous/shake_gobo3,96,103
Miscellaneous/shake_gobo2,104,111 Miscellaneous/shake_gobo1,112,119 Miscellaneous/right_rotate,128,191

2) no_function,0,0 macro_1,16,16 macro_2,30,30 macro_3,48,48 macro_4,64,64 macro_5,78,78 macro_6,94,94 macro_7,110,110 macro_8,128,128 audio1,142,142 audio2,158,158 audio3,176,176 audio4,190,190
audio5,208,208 audio6,222,222 audio7,238,238 audio8,255,255

Revideret 1-10-2023